


RTMP Server File Playback Development Guide

1.1.0.160.0


◆ Introduction

In this document, We will guide user how to implement RTMP file playback of QCAP SDK in the PC website.


1. Create C:\AppServ\www\rtmp\media folder.



2. Put *.flv, *.mp4 files into the folder.



3. User can use RTMP Server sample to create RTMP file playback function.



4. User can see file.mp4 or file.flv on flvplayback.swf.

