


4K RTSP Streaming to VLC with Output Card Development Manual


◆ Introduction

In this document, We will guide user how to implement 4K RTSP Streaming in the VLC Player with Output Card.


1. 4K RTSP.SC510N1.VC2010 sample folder and build the exe.




2. SDI Output cards for SDI graphics-to-video monitors.




3. Select Configure Surround, PhysX in NVIDIA Control Panel.




4. Select Configure button.



5. Topology set 2 x 2 and display select all SDI VGA display and resolution set 3840 x 2160 then Enable Surround.



6. Screen resolution will be 3840 x 2160 if set success.



7. User can see 4K RTSP live streaming on VLC.

